



**ORDER DETAILS**

CODE: 85007.200101

Colours: 909 Steel Grey

Size: 0/S

**TOOLS REQUIRED:**

1 x 2mm Allen Key

**STEP 1:**



Remove the Modular Harness Loop from the Connect Quick Release.

**STEP 2:**



Pull the Quick Release Handle up, in the direction of the arrow.

**STEP 3:**



Using a 2mm Allen Key, remove the screws currently holding the Modular Spring Plate in place.

**STEP 4:**



Remove spring plate and replace with new one.

**STEP 5:**



Re-insert the screws and tighten with 2mm Allen Key to secure the new Modular Spring Plates position.

**STEP 6:**



Release QR Handle then reattach Modular Harness Loop to Connect Quick Release and engage the LockGuard.



**WARNING: Failure to install this product correctly may result in serious bodily injury or death.** Please contact your local North Retailer for support and ask for a qualified and experienced repair shop to carry out the repair. If you choose to carry out this repair yourself, please read and understand all steps contained in this installation guide before commencing installation. Take all necessary safety precautions. Safety precautions may include taking extreme care when using sharp objects and wearing all personal protective equipment necessary.

STEP 7:



Test the Quick Release is functioning correctly.



**WARNING: Failure to install this product correctly may result in serious bodily injury or death.** Please contact your local North Retailer for support and ask for a qualified and experienced repair shop to carry out the repair. If you choose to carry out this repair yourself, please read and understand all steps contained in this installation guide before commencing installation. Take all necessary safety precautions. Safety precautions may include taking extreme care when using sharp objects and wearing all personal protective equipment necessary.