



ORDER DETAILS

CODE: 85007.2000106

Colours: 902 Black Sand

Size: 0/S

TOOLS NEEDED:

- 2.5mm Allen Key
- Long-nosed pliers

STEP 1:



Loosen the set screw in the Cleat Stopper Ball using a 2.5mm Allen Key and push the ball away from the Trim Handle by a few centimetres.

STEP 2:



Pull the figure 8 knot out from inside the Trim Handle, you may need to use some long-nosed pliers to do so. Undo the knot and slide the Trim Handle off.

STEP 3:



Remove the Cleat Stopper Ball. This may require some force.

STEP 4:



Feed the Cleat Stopper Ball and the Trim Handle back onto the Elasticised Trim Line.

STEP 5:



Tie a figure 8 knot in the end of the Elasticised Trim Line and pull tight. The end of the Elasticised Trim Line with the grey mark cloth should sit up against the figure 8 knot when tensioned. Pull the Trim Handle to hide the knot inside.



WARNING: Failure to install this product correctly may result in serious bodily injury or death. Please contact your local North Retailer for support and ask for a qualified and experienced repair shop to carry out the repair. If you choose to carry out this repair yourself, please read and understand all steps contained in this installation guide before commencing installation. Take all necessary safety precautions. Safety precautions may include taking extreme care when using sharp objects and wearing all personal protective equipment necessary.